## Troubleshooting

PROBLEM	SOLUTION
Steamer has NO Power	<ul> <li>Check electrical panel for tripped breaker:</li> <li>➤ The steam cleaner should be the only appliance plugged into the outlet</li> <li>➤ Use only a 12 gauge / 15AMP rated or higher extension cord.</li> </ul>
Power but NO Steam	Check the STEAM DIAL on top of the Eagle.  1) Turn steam control dial to the LEFT.  2) Disconnect the hose and reconnect.  ➤ You will hear a "click" when connected.  1) Check grey safety lock on hose handle.  2) Is the steam number on the display reading "2"?
C T: 1	3) If yes, push and hold power button until it shows a 1 or 3
Squeeze Trigger and NO steam	<ul> <li>Check hose connection:</li> <li>➤ Disconnect and reconnect</li> <li>➤ You should hear a "click" when connecting hose to the steamer</li> <li>➤ Check the grey safety lock on the side of the handle</li> </ul>
Steam pressure last 10 minutes	<ul> <li>You are cleaning using HIGH steam.</li> <li>Reduce steam pressure to MEDIUM.</li> </ul>
Low Water Indicator is flashing	<ul> <li>Add water to the steamer.</li> <li>Push power button to reset alarm.</li> </ul>
Shuts off after 30 minutes	<ul> <li>The Eagle will automatically shut off after 30 minutes of continuous use.</li> <li>Push power button to reset.</li> </ul>
Steamer takes longer than 15 minutes to heat	Have you descaled the boiler?  Your steamer needs to be descaled every 6 months or when you notice a reduction in steam pressure
If you are still havin	ng problems, contact our service team at (817) 888-8313

## Troubleshooting

PROBLEM	SOLUTION
ERROR CODES	E01 – Refill Water Tank E03 – Refilling the boiler failed. E05 – Descale the boiler

If you are still having problems, contact our service team at (817) 888-8313

